



Watson's Streetworks has an extensive line of street rod and custom car and truck parts with one of the largest selections of billet interior trim and electrical accessories.

Check us out on the web at www.watsons-streetworks.com

4 Bud Way, Suite 3, Nashua, NH 03063 866-859-0513
Tech@Watsons-Streetworks.com

GT3 4 Switch Panel

#10141

Custom Switch Panel with your choice of switches. **Switches are rated at a 5 amp maximum load. Additional relays may be required for your application.**

DISCONNECT MAIN POWER AT THE BATTERY
BEFORE DOING ANY WIRING!

- 1. Determine the Location** for the switches in your door or console. Switches mount on top of panel. This requires that you wire switches as a last step. Make sure you leave ample wire for panel removal. See sketches.
- 2. Cut Switch Holes** using the template/ dimensions carefully mark and cut holes.
- 3. Do the Wiring.** The Switches are On/Off, (Momentary On)/ Off, On/Off/On, (Momentary On)/ Off/(Momentary On) Per Your Specifications. The red wire is connected to +12vdc, the gray or yellow wire(s) will be the output.
- 4. Reconnect the main power and test your wiring**

Doing electrical work, but you just aren't quite sure of yourself? Pick up a copy of our Basic Automotive Electricity Book. This fact filled book walks you through electricity from the basics to a complete automotive circuit diagram. And at just \$7.95 it's better than aspirin at solving electrical headaches!