



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. **Please read and understand all installation instructions before beginning.** Planning and preparation will make the entire process easy and quick.

Mechanically Latching SPDT Relay #30018

This relay, uses a Momentary (-) Grounding switch to alternate Between two separate outputs on the relay. Ideal for Hi-Lo Dimmer applications or where a momentary switch is needed to "LATCH" power in the "ON" position.

1. Connect RED wire to +12vdc BATTERY or IGNITION, depending on application.
2. Connect the BLUE wire to momentary grounding switch.
3. The BROWN & WHITE wires are the OUTPUTS.
4. Connect the Purple wire to 12v Battery or Ignition

