




HOOD-DECK RELEASE CABLE INSTALLATION INSTRUCTIONS

1. READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.
 2. LOCATE WHERE YOU WANT HANDLE TO BE MOUNTED
 3. REMOVE CABLE FROM HANDLE
 4. MOUNT HANDLE
 5. RE-ASSEMBLE CABLE TO HANDLE
 6. ROUTE CABLE TO HOOD-DECK. **(TO PROMOTE GREATER CABLE LIFE, AVOID MAKING SEVERE BENDS OR INSTALLING CABLE NEAR ANYTHING THAT GENERATES HEAT).**
 7. NOW THAT THE CABLE IS ROUTED, PULL INNER CABLE OUT OF HANDLE END APPROXIMATELY 2 FEET. CUT OFF EXCESS HOUSING USING A PAIR OF DIAGONAL CUTTERS.
 8. ATTACH HOUSING CAP AT BARE END OF HOUSING BY SLIPPING ON CAP AND GENTLY CRIMP USING A PAIR OF PLIERS.
 9. PUSH INNER CABLE BACK THROUGH HOUSING
 10. MOUNT HOUSING IN PLACE, USING SUPPLIED CLAMPS.
 11. ATTACH INNER CABLE TO LATCH WITH PROVIDED HARDWARE. *
 12. TRIM OFF EXCESS INNER CABLE, USING DIAGONAL CUTTERS.
- **WHEN INSTALLING NO FRAY STOP, DON'T OVER TIGHTEN**

****THESE ARE OPTIONAL CAPS****



GROOVE CAP
P/N 161-579-3



THREADED CAP
P/N 161-581-3