



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. ***Please read and understand all installation instructions before beginning.*** Planning and preparation will make the entire process easy and quick.

EL-MB Billet 3rd Brake Light

Easily Mounted 3rd Super Bright Brake light. With ultra-strong double sided tape, simply mount and wire to your brake switch.

****DISCONNECT ELECTRICAL POWER AT THE BATTERY BEFORE DOING ANY WIRING****

Determine a good location for the light. Clean mounting surface and mount with double sided tape where you can easily run the wires, either through the trunk seam or a preexisting hole. If you must make a new hole, use an 1/8th inch drill bit. Seal hole well with silicone.

