



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. **Please read and understand all installation instructions before beginning.** Planning and preparation will make the entire process easy and quick.

ON/ OFF or MOMENTARY ON/OFF toggle switch with a 6 amp rating	
<u>ON/ OFF TOGGLE Switch (Round Arm)</u>	#L17
<u>MOMENTARY TOGGLE Switch (Round Arm)</u>	#L17M
<u>ON/ OFF TOGGLE Switch (Flat Arm)</u>	#L17F
<u>MOMENTARY TOGGLE Switch (Flat Arm)</u>	#L17FM

****DISCONNECT ELECTRICAL POWER AT THE BATTERY BEFORE DOING ANY WIRING****

Determine a good location for the switch and mount by drilling a 1/4" diameter hole and secure with the hardware included. Wire the switches per the wiring diagram below. Reconnect power and check connections.

