



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. **Please read and understand all installation instructions before beginning.** Planning and preparation will make the entire process easy and quick.

ON/ OFF/ON or MOMENTARY ON/OFF/ MOMENTARY ON toggle switch with a 6 amp rating	
<u>ON/ OFF/ON TOGGLE Switch (Round Arm)</u>	#L17OFO
<u>MOM/OFF/MOM TOGGLE Switch (Round Arm)</u>	#L17MFM
<u>ON/ OFF/ON TOGGLE Switch (Flat Arm)</u>	#L17FOFO
<u>MOM/OFF/MOM TOGGLE Switch (Flat Arm)</u>	#L17FMFM

****DISCONNECT ELECTRICAL POWER AT THE BATTERY BEFORE DOING ANY WIRING****

Determine a good location for the switch and mount by drilling a 1/4" diameter hole and secure with the hardware included. Wire the switches per the wiring diagram below. Reconnect power and check connections.

