

**Watson's**  
**StreetWorks**  
 4 Bud Way #3 Nashua NH 03063  
**866.859.0513**  
[www.watsons-streetworks.com](http://www.watsons-streetworks.com)

**DRIVE IT !**



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car.

*Please read and understand all installation instructions before beginning.*

Planning and preparation will make the actual installation process easy and quick.

This entire document is copyrighted 2016, StreetWorks LLC.

**Contemporary Turn Signal Lever (GM)  
with 3 Amp ON/OFF Switch**

**#L43G**

Tilt Lever with S/S arm & aluminum knob to fit GM 1/4-28 threads has an ON/OFF switch hidden in the nob. Use for ON/OFF switching to 3 Amps max.

To install the turn signal lever simply screw it in place into the same hole that the original factory turn lever occupied using the screw provided. After installing the lever, carefully fish the lead wires down through the column and wire.

If greater amperage capacity is needed, a relay is required. See our #L07-40, #L07D-40, #L07-80, etc. depending upon your application. Wire per the relay instructions.

**Positive Switching**

**Ground Switching**

**- OR -**

