StreetWorks 866 859 0513 4 Bud Way, Suite 3, Nashua, NH DRIVE IT!

Please read and understand all installation instructions before beginning. Planning and preparation will make the actual installation process easy and quick.

DISCONNECT ELECTRICAL POWER AT THE BATTERY BEFORE DOING ANY WIRING!

- **1. SWITCH MOUNTING** may be done in the dash or console. Use the template below to make the hole for mounting, then install the switch.
- 2. SWITCH CONNECTIONS (a) Connect the red lead wire to +12 volt dc, fused per above. (b) Connect the gray lead(s) to the circuit(s) to be switched. #L55 is an On/Off switch and #L55M is a Momentary (On)/Off switch and will have only one gray output wire.
- 3. RECONNECT main power and test your connections.

DI 401/	DOOKED	OMME 011
BLACK	ROCKER	SWITCH

ON / OFF (10 AMPS)

#L55

MOM. (ON) / OFF (5 AMPS)

#L55M

ON / OFF / ON (5 AMPS)

#L550F0

MOM.(ON) / OFF / MOM.(ON) (5 AMPS)

#L55MFM

Hole Template



