

## **LSS-57 WIRE LOOMS**

### **INSTALLATION DIRECTIONS**

EVERY INSTALL WILL VARY THIS WILL  
BE AN EXAMPLE INSTALLED IN 39  
YOUR APPLICATION MAY VARY AS TO  
MOUNTING THE STATIONARY (PART WITH  
SET SCREW IN IT) IN "A" POST OR DOOR

- STEP # 1 With door shut, drill a pilot hole between door and "A" post.
- STEP # 2 Drill a 3/4" diameter hole in "A" post.
- STEP # 3 Drill a 5/8" diameter hole in the door.
- STEP # 4 Mount 3/4" fitting in "A" post and secure with collar with set screw.
- STEP # 5 Mount 5/8" fitting in door and secure with collar with set screw.
- STEP # 6 5/8" fitting has set screw to adjust travel between door and "A" post, at this point insert black tubing into 5/8" fitting, check necessary travel and adjust.
- STEP # 7 Repeat for other door.
- STEP # 8 Insert wiring into looms.

**MADE WITH PRIDE  
IN AMERICA**