Doing electrical work but you just aren't quite sure of yourself? Pick up a copy of our Basic Auto Electricity Book. This fact filled book walks you through electricity from the basics to a complete automotive circuit diagram. It's a small price to pay for solving electrical headaches!

Watson's StreetWorks has an extensive line of street rod and custom car and truck parts with one of the largest selections of billet interior trim and electrical accessories. Check us out on the web at www.watsons-streetworks.com.

## Thank you for buying our products!



## 6-LED Clearance/Marker Light #L96 Series

Clearance/Marker Light comes with a rubber grommet for easy installation into a 1-3/8" diameter hole and an optional polished Stainless Steel Grommet Cover/Trim Ring. Low amperage draw, compact, meets DOT P2PC requirements, 100,000 hour rated life, waterproof. 1-7/8" overall diameter. 12 vdc.

## Supplied by Watson's StreetWorks Rod & Custom Products

Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car.

Please read and understand all installation instructions before beginning.

Planning and preparation will make the entire process easy and quick.

DISCONNECT POWER AT THE BATTERY BEFORE DOING ANY WIRING!

If you are going to use the optional S/S trim ring/grommet cover, remove the LED light from the rubber grommet and reinstall with the S/S ring between the two.

The light mounts into a 1-1/4" diameter hole. Simply push the assembly into the hole until the grommet seats. NOTICE that the lens is marked with the word "TOP" and should be so oriented for use as a clearance light.

Wire: white is ground, black is +12 vdc power.