



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. ***Please read and understand all installation instructions before beginning.*** Planning and preparation will make the entire process easy and quick.

## NOTES

This kit does ***NOT*** provide the security of a key lock ignition switch so alternate security measures are required and are the sole responsibility of the consumer. We offer a few different security options that work very well with this product.

**Accessories:** This Circuit is good for up to 30amps. If your setup requires more than 30 amps you **MUST** run a relay of sufficient size.

**Carbureted? - NO PROBLEM.** Our module will “PRIME” your system momentarily before the starter circuit is engaged through the accessory circuit.

**FUEL INJECTED? -** The “PINK” wire on our module is the “RUN” circuit, or “IGN” wire off a standard key. If your system requires more than 10 amps on the “RUN” circuit a relay will be required.

**Red Power Wire:** Included you will find an ato/atc fuse holder. You ***MUST*** put this inline on your red power wire. If you do not put this fuse inline you will void your warranty.

**Brown Wire / Acc. Feed:** This wire is good for up to 30amps. If your setup requires more than 30 amps you **MUST** run a relay of sufficient size.

***The NEW and IMPROVED***

**#L75X**

## **(Ignition / Accessory / Start / Stop Switch)**

Replace your old keyed ignition switch with our modern “Hot Dot” Push Button Starter Kit. The modern switch mounts in a 7/8” diameter hole. When activated the switch illuminates in a RED LED ring.

*Please see **NOTES** before wiring. Refer to your specific ignition system requirements. Please call us if you are unsure or have any questions.*

**ALWAYS Disconnect POWER at the BATTERY before doing any wiring!**

### HOW IT WORKS

**Accessories (On/Off),** Press & Release button.

**Start Mode,** Press and hold for 1-1/2 seconds, press and release to SHUT DOWN.

(You may also enter START MODE from ACCESSORY (On) Mode.)

You will not be able to re-start your vehicle from the “Run” position as this has been programmed out as a safety feature.

### IGNITION MODULE WIRING

We have identified the comparable ignition switch connections (Battery, Ignition, Start and Accessory) along with our switch. When using a switch other than ours, the YELLOW wire from the module supplies +12vdc for switch illumination. The BLUE wire is the control wire for the module.

### RELATED PRODUCTS

**#WI-RFID:** A seamless RFID security system for your Hot Dot. (Radio Frequency Identification)

**#L07-80:** 70 amp relay.

