



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car.

Please read and understand all installation instructions before beginning. Planning and preparation will make the actual installation process easy and quick.

NOTE: Our lights meet or exceed all requirements for brightness. However state and local laws vary regarding lens size and placement. It is *your* responsibility to assure that the lights are acceptable for use in your state and locale.

1. Determine the location for the units. The acrylic lenses will be able to accommodate about 1/4" of total curvature. It may be necessary to modify the surface in the area where the lenses are to be installed to accommodate a straighter surface. Do not expect or attempt to bend the acrylic lenses - they will break. The LEDs can be installed either horizontally or vertically as your application determines **but remember** that LED's must point horizontally as the vehicle sits level. Plan as you build so that any spacers or modifications to the sheet metal/fiberglass are done to achieve these end results.

2. Layout the lens slots. We recommend that you first have available (or make) a .500" wide block to use as a test gauge for the slot. **DO NOT** use the acrylic lens as a test gauge nor try to force the lens into place! Carefully layout and then drill/cut the slot opening for the lenses. Drill (2) .500" Diameter holes that are 7.00" apart center-to-center (7.500" total slot width). Then cutout the slot between the holes. NOTE: Standard drill bits do not always make a nice round hole! We recommend that you be conservative and hand work the holes up to the correct size. It is not life-and-death critical that the hole size not get too large, it can be fixed later, but the closer the size, the straighter the edges and the more carefully you do the holes the first time, the better the overall job will be. Properly sized, the lens will cleanly go into the slot with no friction. Remember that there will be a small amount of paint buildup on the edge before final installation.

3. Prepare for LED Housing attachment. We have included screws for use as studs for attaching the LED Housings. These should be welded, fiberglassed or epoxied into the body - BE SURE that they are absolutely secure. To best determine the stud location, temporarily tape a lens into the hole and then place the housing over the lens/diffuser. You will notice that the housing goes over the diffuser and "self-locates". Mark and install the studs. In many cases you may tape the lens FROM THE OUTSIDE IN to do the marking so that it will be easier to see and mark for the studs. If the LED's are going to be properly horizontal for best viewing, the studs will also be very close to horizontal. Double check all fit and alignment before proceeding.

4. Body work. The entire area around and including the lens hole should be worked to the exact contour you want for the finished surface. This will reduce the amount of work needed after the lens is installed. Also, you want to get final color on the surface immediately around the acrylic lens AS SOON AS POSSIBLE to prevent subsequently sanding through to reveal filler or primer. You want the last sanding of the lens to leave the lens surface perfectly flush with color paint.

5. Lens Installation. With steps #2, 3 and 4 above completed, permanently epoxy the lenses into place from the inside. Be very careful not to use too much or to get the epoxy on the light transmission surface. Add more color paint as filler around the lens as needed and carefully begin to do the bodywork to "flush" the lenses to the body as one unit - carefully block sanding so as not to work the acrylic lower than the surrounding surface or to sand through color paint surface. When getting "close" to smooth, shoot with color and wet sand back smooth. Repeat and again wet sand back smooth to reveal all of the lens. Finally, clear coat over the paint, lenses and all then finish sand/polish. (You may mask off the lenses before painting if you prefer.) Repeated clear coats may be needed to buildup and smooth the area.

**Small "Hot Slots" Flush Mount,
 Build- in White LED Running Light /
 Amber LED Turn Signal Kit (pair)**

#L58SM-WACL

- (4) High Bright White LED Running Light Clusters plus 12 Super Bright Amber LED's in each aluminum housings with wire leads and hardware for stud mounting.
- (2) preshaped 1/4" thick amber acrylic lenses with diffuser for build-in flush installation with 1/2" x 7-1/2" size.
- Works with other LED or standard signals - no complicated control module required.


NOTE: This is a build-in kit requiring body working skills and is intended for vehicles that are under construction or modification.

#L58SM-WACL "Hot Slots" Flush Mount, Build-in LED Taillight Kit Instructions - continued

6. **The LED Housings** are aluminum and should be primed/painted on the outside to prevent corrosion. Install using the hardware provided. A small amount of RTV or silicone chalk may be desirable to assure a watertight seal.

7. **Wire per the diagram below.** Then reconnect power and check the light function.

7a. For Turn Signal Wiring:



7b. For Running Light Wiring (not shown):

The larger white wires on the White LED clusters are the ground wires, Connect together and then connect to ground.

The larger black wires on the White LED clusters are the hot feed wires. Connect together and wire to an accessory circuit that is on whenever the vehicle is running. The total amperage draw will be about 1/4 amp per side.

As a last step, add RTV or Silicone caulk to fill around the edge of the opening for a water tight seal.

Please Note:
The entire LED housing **MUST BE** sealed tightly to prevent dirt and moisture from damaging LED's and voiding your warrantee.

NOTE: When using LED lights for turn signals with standard flashers, the LED may not draw enough amperage to work the flasher (unless you have regular bulbs elsewhere in the system). If there is a problem with the flasher, you will need either a "dummy" load or special flasher unit.