## StreetWorks 866.859.0513

4 Bud Way, Suite 3, Nashua, Ni

DRIVE IT !



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. *Please read and understand all installation instructions before beginning.* Planning and preparation will make the actual installation process easy and quick.

**NOTE:** Our lights meet or exceed all requirements for brightness. However state and local laws vary regarding lens size and placement. It is *your* responsibility to assure that the lights are acceptable for use in your state and locale.

## "Hot Slots" Flush Mount, Build- in Rectangular LED Park Light Kit (pair)

#L63AN

Kit includes:

- ☐ (2) High Bright AMBER 4 LED Park Light Slot units with aluminum housings, wire leads and hardware for stud mounting.
- □ (2) 1/2" thick clear acrylic lenses with diffuser for build-in flush installation with compact 1/2" X 1-3/4" size.
- (2) Conversion kits for double intensity function.
- Works with LED or standard rear signals.

**NOTE**: This is a build-in kit requiring body working skills and is intended for vehicles that are under construction or modification.

- 1. <u>Determine the location for the units</u>. The acrylic lenses will be able to accommodate about 1/2" of total curvature. It may be necessary to modify the surface in the area where the lenses are to be installed so as to accommodate a straighter surface. Do not expect or attempt to bend the acrylic lenses they will break. Don't mount the units too low or they may be hard to see. Remember that LED lights are very directional and must set horizontally as the vehicle sits level. Plan as you build so that any spacers or modifications to the sheet metal/fiberglass are done to achieve these end results. See the diagram on the back.
- 2. <u>Layout the lens holes</u>. We recommend that you first have available (or make) a 0.500" wide block to use as a test gauge for the holes. **DO NOT** use the acrylic lens as a test gauge nor try to force the lens into place! Carefully layout and then drill/cut the opening for the lenses. We recommend that you be conservative and hand work the holes up to the correct size. It is not life-and-death critical that the hole size not get too large, it can be fixed later, but the closer the size and the more carefully you do the holes the first time, the better the overall job will be. Properly sized, the lens will cleanly go into the hole with no friction. Remember that there will be a small amount of paint buildup on the edge before final installation.
- 3. Prepare for LED Housing attachment. We have included screws for use as studs for attaching the LED Housings. These should be welded, fiberglassed or epoxied into the body BE SURE that they are absolutely secure. To best determine the stud location, temporarily tape a lens into the hole and then place the housing over the lens/diffuser. You will notice that the housing goes over the diffuser and "self-locates". Mark and install studs. In many cases you may tape the lens FROM THE OUTSIDE IN to do the marking so that it will be easier to see and mark for the studs. If the LED's are going to be properly horizontal for best viewing, the studs will also be very close to horizontal. Double check all fit and alignment before proceeding.
- 4. <u>Body work</u>. The entire area around and including the lens hole should be worked to the exact contour you want for the finished surface. This will reduce the amount of work needed after the lens is installed.
- 5. Lens Installation. With steps #2, #3 and 4 above completed, permanently epoxy the lenses into place. Be very careful not to use too much or to get the epoxy in the way of subsequent housing installation. Add filler around the lens as needed and carefully work it down to the final lens level. (IMPORTANT TIP: You want to get final color on the surface immediately around the acrylic lens AS SOON AS POSSIBLE to prevent subsequently sanding through to reveal filler or primer. You want the last sanding of the lens to leave the lens surface perfectly flush with color paint.) Do the bodywork to "flush" the lenses to the body as one unit carefully block sanding so as not to work the acrylic lower than the surrounding surface. When getting "close" to smooth, shoot with color and wet sand back smooth. Repeat and again wet sand back smooth to reveal all of the lens. Finally, clear coat over the paint, lenses and all then finish sand/polish. (You may mask off the lenses before painting if you prefer.) Repeated clear coats may be needed to buildup and smooth the area.

## "Hot Slots" Flush Mount, Build-in Rectangular LED Park Light Kit Instructions - continued

- 6. <u>The LED Housings</u> are aluminum and should be primed/painted before use to prevent corrosion. When ready for final installation, install the LED unit into the housing using the quality 3M tape provided be sure to center the LED unit in the housing. Then install the LED and housing using the hardware provided. A small amount of RTV or silicone caulk may be desirable around the installed housing to assure a watertight seal.
- 7. Wire per the diagram below. Then reconnect power and check the light function.

