

Doing electrical work but you just aren't quite sure of yourself? Pick up a copy of our Basic Auto Electricity Book. This fact filled book walks you through electricity from the basics to a complete automotive circuit diagram. And at just \$7.95, it's better than aspirin at solving electrical headaches!

Switched Dome/Interior Light

#L82

Kit includes:

- Dome Light housing.
- Clear Lens.
- Built-in Switch.
- Bulb and Wire Leads.

Manufactured by Watson's StreetWorks Rod & Custom Products

Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. *Please read and understand all installation instructions before beginning.* Planning and preparation will make the entire process easy and quick.
DISCONNECT POWER AT THE BATTERY BEFORE DOING ANY WIRING!

1. Our light mounts onto a flat surface and should have a "hard" surface to mount against. If you are mounting the light against a soft head liner material, be sure to have a hard backing that the light housing and lens can set against and into (also see diagrams on the reverse side of this page). Padding between the backing and headliner is OK as long as the total thickness of the headliner, padding and backing equals about 1/4" - 3/8".

2. The hard mounting surface or backing needs a hole cutout per the template on the reverse side of this instruction. Be sure to compare the light to the template to properly understand how the light is mounted and installed. There should be no flammable material directly above the center bulb area - allow for ventilation.

Watson's StreetWorks has an extensive line of street rod and custom car and truck parts with one of the largest selections of billet interior trim and electrical accessories. Check us out on the web at www.watsons-streetworks.com.

Thank you for buying our products !

Watson's
StreetWorks
4 Bud Way, Ste 3, Nashua NH 03063
866.859.0513
Tech@watsons-streetworks.com


DRIVE IT !





StreetWorks Switched Dome/Interior Light Instructions - continued

3. Trial fit the unit and adjust as needed. The housing can be used as-is, or it can be painted after priming with a suitable plastic primer.
4. Wire the unit as shown in the diagrams at right.
5. With the wiring complete, install the unit into the hole.



Hole Template

