


Watson's

StreetWorks

4 Bud Way, Ste 3, Nashua NH 03063
866.859.0513

Tech@watsons-streetworks.com

DRIVE IT !



Thank you for buying a StreetWorks product. Be confident that it will provide the quality and performance that you demand for your car. **Please read and understand all installation instructions before beginning.** Planning and preparation will make the actual installation process easy and quick.

NOTE: Our lights meet or exceed all requirements for brightness. However state and local laws vary regarding lens size and placement. It is *your* responsibility to assure that the lights are legally acceptable for use in your state and locale.

1. Determine the location for the units. The acrylic lenses will be able to accommodate about 1/4" of total curvature. It may be necessary to modify the surface in the area where the lenses are to be installed so as to accommodate a straighter surface. Do not expect or attempt to bend the acrylic lenses - they will break. Don't mount the units too low or they may be hard to see from behind. These Sequential LEDs should be installed horizontally **and remember** that LED taillights must point straight backwards, that is, horizontally as the vehicle sits level and, preferably, be reasonably close to eye level. Plan as you build so that any spacers or modifications to the sheet metal/fiberglass are done to achieve these end results.

2. Layout the lens slots. We recommend that you first have available (or make) a .500" wide block to use as a test gauge for the slot. **DO NOT** use the acrylic lens as a test gauge nor try to force the lens into place! Carefully layout and then drill/cut the slot opening for the lenses. Drill (2) .500" Diameter holes that are 14.750" apart center-to-center (15.250" total slot width). Then cutout the slot between the holes. **NOTE:** Standard drill bits do not always make a nice round hole! We recommend that you be conservative and hand work the holes up to the correct size. It is not life-and-death critical that the hole size not get too large, it can be fixed later, but the closer the size, the straighter the edges and the more carefully you do the holes the first time, the better the overall job will be. Properly sized, the lens will cleanly go into the slot with no friction. Remember that there will be a small amount of paint buildup on the edge before final installation.

3. Prepare for LED Housing attachment. We have included screws for use as studs for attaching the LED Housings. These should be welded, fiberglassed or epoxied into the body - BE SURE that they are absolutely secure. To best determine the stud location, temporarily tape a lens into the hole and then place the housing over the lens/diffuser. You will notice that the housing goes over the diffuser and "self-locates". Mark for, and install the studs. In many cases you may tape the lens FROM THE OUTSIDE IN to do the marking so that it will be easier to see and mark for the studs. If the LED's are going to be properly horizontal for best viewing, the studs will also be very close to horizontal. Double check all fit and alignment before proceeding.

4. Body work. The entire area around and including the lens hole should be worked to the exact contour you want for the finished surface. This will reduce the amount of work needed after the lens is installed.

5. Lens Installation. With steps #2, #3 and 4 above completed, permanently epoxy the lenses into place. Be very careful not to use too much or to get the epoxy in the way of subsequent housing installation. Add filler around the lens as needed and carefully work it down to the final lens level. (**IMPORTANT TIP:** You want to get final color on the surface immediately around the acrylic lens AS SOON AS POSSIBLE to prevent subsequently sanding through to reveal filler or primer. You want the last sanding of the lens to leave the lens surface perfectly flush with color paint.) Do the bodywork to "flush" the lenses to the body as one unit - carefully block sanding so as not to work the acrylic lower than the surrounding surface. When getting "close" to smooth, shoot with color and wet sand back smooth. Repeat and again wet sand back smooth to reveal all of the lens. Finally, clear coat over the paint, lenses and all then finish sand/polish. (You may mask off the lenses before painting if you prefer.) Repeated clear coats may be needed to buildup and smooth the area.

**"Hot Slots" Sequential Flush Mount, #L58-SEQ
Build- in LED Taillight Kit (pair)**

- (2) High Bright 60 LED Taillight units in aluminum housings, split 20-20-20 for sequencing, with wire leads and hardware for mounting.
- (2) preshaped 1/4" thick red acrylic lenses with diffuser for build-in flush installation with large 1/2" x 15-1/4" size.
- Sequencing modules and taillight / turn signal convertors.
- Electronic LED Flasher.

NOTE: This is a build-in kit requiring body working skills on vehicles with a common bulb for brake light and turn signal. Vehicles with separate (amber) turn signals should purchase our kit #L72-SEQ.



"Hot Slots" Sequential Flush Mount, Build-in LED Taillight Kit Instructions - continued

6. **The LED Housings** are aluminum and should be primed/painted on the outside to prevent corrosion. Install using the hardware provided. **The RED wire feeds the INSIDE end of the light.** Test your orientation to give proper inside-out sequencing. A small amount of RTV or silicone chalk will be desirable to assure a watertight seal.

7. **Wire per the diagram below.** Then reconnect power and check the light function.

Wiring Diagram - one side shown, duplicate for other side.

Connect the red wire from the light housing to +12 vdc and ground the black wire to determine which end of the LED Light Housing is the "Inside End".



As a last step, add RTV or Silicone caulk to fill around the edge of the opening for a water tight seal.

Please Note:
The entire LED housing **MUST BE** sealed tightly to prevent dirt and moisture for damaging LED's and voiding your warrantee.

NOTE: This kit is for vehicles with a common bulb for brake light and turn signal. Vehicles with separate (amber) turn signals should purchase our kit #L72-SEQ.